





ê \$´ šsX PÁ/ ТрѢр-` ò* =

<http://www.ruijiery.com/>

<http://ocs.ruijie.com.cn/?p=smb>

<http://www.ruijie.com.cn/service.aspx>


7

4001-000-078

<http://bbs.ruijiery.com/>

<http://www.ruijie.com.cn/service/know.aspx>

4001000078@ruijie.com.cn




1

NBR3000D-UE
NBR3000D-UE

1.1 RG-NBR3000D-UE

	RG-NBR3000D-UE		
	DDR3 SDRAM 2GB		
	BOOTROM 8MB		
	FLASH 512MB		
	SATA 500GB		
I/O	WAN		
	2	10/100/1000M	
	WAN1	WAN/LAN	
	WAN0	WAN1	1000BASE-SX/LX/ZX mini GBIC
	GE-SFP-LX20/LH40		



1-2 RG-NBR3000D-UE



PWR			
SYS			
SATA			
0-7	link/ACT	/ /	Link
0-7	speed	/	
6F-7F		link	

2

2.1

UPS

10

2

2.2

2.2.1 /

2.2.5


19"

2.3

	HUBAPP

3

3.1 NBR3000D-UE



3.2 NBR3000D-UE

NBR3000D-UE

NBR3000D-UE


3.3

NBR3000D-UE	100-240V~/50-60Hz
-------------	-------------------


3.4

1Ω NBR3000D-UE 1


3-1 NBR3000D-UE



3.5



4-3



4-4

“ ”

NBR3000D-UE

Boot 1.3.12-00503-ga15871f (Build time: Nov 25 2015 - 10:13:23)

DRAM: 2 GiB

NAND: 512 MiB

Flash: 8 MiB

SETMAC: Setmac operation was performed at 2016-01-06 11:03:10 (version: 11.0)

Press Ctrl+C to enter Boot Menu

Creating 1 MTD partitions on "nand0":

0x0000000000000-0x0000010000000 : "mtd=0"

UBI: attaching mtd2 to ubi0

UBI: physical eraseblock size: 131072 bytes (128 KiB)

UBI: logical eraseblock size: 129024 bytes

UBI: smallest flash I/O unit: 2048

UBI: sub-page size: 512

UBI: VID header offset: 512 (aligned 512)

UBI: data offset: 2048

UBI: attached mtd2 to ubi0

UBI: MTD device name: "mtd=0"

UBI: MTD device size: 16 MiB

UBI: number of good PEBs: 128

UBI: number of bad PEBs: 0

UBI: max. allowed volumes: 128

UBI: wear-leveling threshold: 4096

UBI: number of internal volumes: 1

UBI: number of user volumes: 1

UBI: available PEBs: 9

UBI: total number of reserved PEBs: 119

UBI: number of PEBs reserved for bad PEB handling: 2

Starting vlan_terminal.elf...

[OK]

Starting webservice.elf...

Starting webservice.elf...

[OK]

html decompress.

html decompress.

[OK]

Starting php-fpm...create /var/run/php-fpm.pid done...

Starting

5

5.1

NBR3000D-UE

PWR