


ISG

Contents

ISG





UAC 6000-ISR200




UAC 6000-ISR40



UAC 6000-ISR10



UAC 6000-ISR02



UAC 6000-ISG02



Console RJ45

USB BIOS

PWR power HDD
bypass

BYP

5 MGT E10 IP
>WAN1 bypass LAN2<->WAN2

LAN1<-

UAC 6000-ISG10

PWR power

HDD

Console RJ45

USB BIOS

BYP1 BYP2 bypass

6 LAN1\MGT


IP
bypass

LAN1<->WAN1 LAN2<->WAN2

LAN3<->WAN3 bypass

4 4

UAC 6000-ISG40



USB

BIOS

Console

RJ45

;

MGT

MGT1

IP

MGT2

ERR

PWR power

HDD

4


4

8

2



UAC 6000-ISG200



USB		BIOS					
Console		RJ45		;			
MGT			MGT1		IP		MGT2
ERR						PWR	power
			HDD				
	4	4	8		2		

Contents



DDOS

UAC 6000-ISG02/ISG10/ISG40/ISG200



ISG

UAC 6000-ISG02/ISG10/ISG40/ISG200

www.ruijie.com.cn

www.ruijie.com.cn/service.aspx

bbs.ruijie.com.cn

webchat.ruijie.com.cn

4008-111-000