

RG-III-N86A

---

copyright © 2017





---



--	--	--	--

( )

	(Model)	(Parameter)
(Display)	LCD (Size)	86"
	LCD	A
	(Backlight type)	LED
	(Resolution)	3840*2160 (pixels)
	(Brightness) (typ)/(min)	350cd/m <sup>2</sup> (min.)
	(Brightness) (typ)/(min)	400cd/m <sup>2</sup> (typ.)
	(Contrast Ratio) (typ)/(min)	1200:1 (typ.)
	(Response Time) (typ)/(min)	8ms (typ.)
	(Pixel Pitch)	0.4935mmx0.4935mm
	(Refreshing frequency)	60Hz
	(Viewing angle)	178°(H)/178°(V)
	(Life Time) (typ)/(min)	30,000 hrs (min.)
	(Color Gamut)(X% NTSC)	65%
	(View area)	1897mmx1068mm
	(Display Colors)	1.07B(10bit)
	16:9	
	10000K	
	2G	
	16G/EMMC	
	9.0	
	Intel I5-8400	
	8G	
	256 SSD	
	WINDOW 10	


---




---

---

---

	10% ~ 90% RH Non-Condensing
	0 5000
MIBF	3
	45db

( )

1

2

3


---

4






5



( )

( )

5 -			
1 -			
3 -			
2 -			
4 -			



1号

2号



3号



( )



		2000mm*1224mm*90mm	60KG
86	4024mm*1224mm*90mm	1012mm*1224mm*90mm	35KG




3 M6 5 M8\*150 1 M8\*80  
+M4\*30



5

ok





( )

---

---

( )

( )

---

# Trouble shooting

1

1

2

现象	解决方案
没有图像 没有声音	<ul style="list-style-type: none"><li>检查是否插上电源线。</li><li>按本机或遥控器上的POWER键检查是否为待机状态。</li></ul>
声音正常但色彩不佳	<ul style="list-style-type: none"><li>选择合适的图像模式。</li><li>调节图像的亮度。</li></ul>
色彩不佳	<ul style="list-style-type: none"><li>调节图像的色彩饱和度。</li></ul>
图像正常，没有声音	本机是否处于静音状态，按静音键取消静音。

3

Windows 10

