


RG-ES08, ES08G

Series Switch Quick Installation Guide

!

A66

16F503PF740k7



1

1		1	
2	1.2m	1	
3		1	

(1)

M3

(2)



a b



! A66

16F A03PF740

+k7 >



1~8

www.ruijie.com.cn

Copyright © ruijie networks Co., Ltd.

618

<http://bbs.ruijiery.com>

+86-400-100-0078(China)

<https://www.ruijiery.com>

<https://www.ruijie.com.cn>

Ruijie Ethernet Switches Installation Quick Start

This quick start applies to RG-ES08 and RG-ES08G, the execution standards include GB 4943.1.

Operation of this equipment in a residential environment could cause radio interference.

1: Nameplate on the bottom of the device.

Package Contents

Number	Item	Quantity
1	Switch	1
2	Power adapter (power cord length 1.2 m)	1
3	Quick Installation Guide	1

Install the Device

Wall Mounting

- (1) Step1: Drill two holes in the wall based on the distance between the two slots on the bottom panel of the switch. Pu[O]-4(gBDC q418.15 337.25 120.38 17)13(e)-3(e)-3(n)-3(t)-3(h)9(e)-3(t)-3(w)15(o)-3(s)-8(l)-4(o)Tm0.1339 Tm[S

Desktop Mounting

Place the switch upside down on a stable and flat desktop.

Connect the Device

Refer to scenario **A** or **B** for networking guidance based on your actual situation.



Opn ode0g 23(a)-ct -babQubasocrkid oInsidotua ovdMcea9-5(l)6(e)-3(i)-4a(b)[Q]-5(a)9(s)- r(d)-3(o)d(c)7(r9)9.ce

For more information about the product and installation procedures, log in to www.ruijie.com.cn

Copyright © ruijie networks Co., Ltd.

RUIJIE NETWORKS CO., LTD.

Ruijie Science and Technology Park, Juyuanzhou, No. 618, Jinshan Road, Fuzhou

Technical Support: <http://bbs.ruijiery.com> Technical Support Hotline: +86-400-100-0078(China)

Website: <http://www.ruijiery.com> <http://www.ruijie.com.cn>